

NAME

vs – voice synthesizer interface

DESCRIPTION

Bytes written on *vs* drive a Federal Screw Works Votrax® voice synthesizer. The upper two bits encode an inflection, the other 6 specify a phoneme. The code is given in section *vs* (VII).

Touch-Tone® signals sent by a caller will be picked up during a *read* as the ASCII characters {0123456789#*}.

FILES

/dev/vs

SEE ALSO

speak (VI), vs (VII)

BUGS