

**NAME**

vs – voice synthesizer code

**DESCRIPTION**

The octal codes below are understood by the Votrax® voice synthesizer. Inflection and phonemes are or-ed together. The mnemonics in the first column are used by *speak* (I); the up-  
per case mnemonics are used by the manufacturer.

0	300	4–strong inflection	u0	014	UH–but
1	200	3	u1	015	UH1–uncle
2	100	2	u2	016	UH2–stirrup
3	000	1–weak inflection	u3	034	UH3–app_le ab_le
			yu	027	U–use
a0	033	AH–contact	iu	010	U1–unite(,y1,iu,...)
a1	052	AH1–connect	ju	011	IU–new
aw	002	AW–law(,l,u2,aw)	b	061	B
au	054	AW1–fault	d	041	D
ae	021	AE–cat	f	042	F
ea	020	AE1–antenna	g	043	G
ai	037	A–name(,n,ai,y0,m)	h	044	H
aj	071	A1–namely	k	046	K
e0	004	EH–met enter	l	047	L
e1	076	EH1–seven	m	063	M
e2	077	EH2–seven	n	062	N
er	005	ER–weather	p	032	P
eu	073	OOH–Goethe cheveux	q	075	Q
eh	067	EHH–le cheveux	r	024	R
y0	023	EE–three	s	040	S
y1	026	Y–sixty	t	025	T
y2	035	Y1–yes	v	060	V
ay	036	AY–may	w	022	W
i0	030	I–six	z	055	Z
i1	064	I1–inept inside	sh	056	SH–show ship
i2	065	I2–static	zh	070	ZH–pleasure
iy	066	IY–cry(,k,r,a0,iy)	j	045	J–edge
ie	003	IE–zero	ch	057	CH–batch
ih	072	IH–station	th	006	TH–thin
o0	031	O–only no	dh	007	THV–then
o1	012	O1–hello	ng	053	NG–long ink
o2	013	O2–notice	–0	017	PA2–long pause
ou	051	OO1–good should	–1	001	PA1
oo	050	OO–look	–2	074	PA0–short pause

**SEE ALSO**

speak(I), vs(IV)